


Wall Panel
Panneau mural


Assembly Instructions
Instructions d'assemblage



logiflex


Components | Pièces

Wall Panel
Panneaux murale



Hardware | Quincaillerie

Support (black)
Attaches (noir)



4x

Sets | Ensembles

Screw | Vis
#6 - 5/8"



8x

Screw | Vis
#8 - 1-1/2"



8x

Wall Anchor
Ancre mural




2x

IMPORTANT NOTE | NOTE IMPORTANTE




This hardware provides a permanent or temporary installation. If you want to have the possibility to remove the wall panel, break the little plastic tongue in the center of the black "female" support piece. | Cette attache fournit une installation permanente ou temporaire. Si vous souhaitez avoir la possibilité de retirer le panneau mural, casser la petite languette en plastique située au centre de l'attache "femelle" noire.



1 Installing the Supports | Installer les attaches

- 1.1** Screw the black 'male' supports to the back of the wall panel with the supplied screws following the pre-drilled marks. | Vissez les attaches "mâles" noires à l'arrière du panneau mural avec les vis fournies à l'aide du marquage.



Support
Attache



4x


Screw | Vis
#6 - 5/8"



8x

2 Preparing the Wall | Préparer le mur

- 2.1** Prepare the wall by tracing the wall panel's dimensions. | Préparez le mur en traçant les dimensions du panneau.
- 2.2** Print the paper template on page 4 of this document at 100%. Verify that the measurements on the template are accurate. | Imprimez le gabarit en papier à la page 4 de ce document à 100%. Vérifiez que les mesures sur le modèle sont exactes.
- 2.3** Align the corners of the paper template to its corresponding corner on the lines that were previously drawn on the wall and mark the wall with a nail or pencil where the hole is to be drilled. | Alignez les coins du gabarit en papier sur le coin correspondant des lignes précédemment tracées sur le mur et marquez-le avec un clou ou un crayon à l'endroit où le trou doit être percé.



④ Pre-Drill Holes | Trous pré-perçés

- 4.1 Using a 1/4" drill bit, drill holes according to the markings on the wall in the previous step. | À l'aide d'une mèche de 1/4", percez les trous en suivant les indications sur le mur de l'étape précédente.




⑤ Insert Anchors | Insérer des ancrés

- 5.1 Hammer the supplied anchors into the drilled holes in the wall. | Enfoncez les ancrages fournis dans les trous percés dans le mur.

Wall Anchor
Ancrage mural



8x




⑥ Installing the Supports to the Wall | Installer les attaches au mur

- 6.1 Screw the "female" support to the wall using the supplied screws. | Vissez l'attache "femelle" au mur à l'aide des vis fournies.

Screw | Vis
#8 - 1-1/2"




8x



⑦ Installing the Wall Panel to the Wall | Installer le panneau au mur

- 7.1 To install the wall panel to the wall, slide the two portions of the supports into each other. | Pour installer le panneau mural contre le mur, faites glisser les deux parties des attaches l'une dans l'autre.




As our product line is constantly evolving and expanding, we recommend that you visit logiflex.ca for updates.
En raison de l'évolution constante des lignes de produits, Logiflex vous encourage à consulter les mises à jour au logiflex.ca.

logiflex


1235 St-Roch N., Sherbrooke QC J1N 0H2 Canada
T : 1.877.864.9323 | F : 1.800.474.7830 | logiflex.ca

Left corner top
Coin supérieur gauche




Wall Panel Drilling Template

Prepare the wall by tracing the wall panel's dimensions.




Left corner bottom
Coin inférieur gauche

Right corner top
Coin supérieur droite



Gabarit de perçage pour panneau mural

Préparez le mur en traçant les dimensions du panneau.



Right corner bottom
Coin inférieur droite

