



6 Attaching the Removeable Panel | Fixer le panneau amovible

6.1 Attach the removeable panel to the plastic clips. |
Fixer le panneau amovible aux clips en plastique.




Link

**Assembly Instructions
Instructions d'assemblage**



Components | Pièces



Hardware | Quincaillerie

Pin Cam	Cam	Wood Dowel Goujon de bois	Screw Vis 30mm, 1/4" - 20
			
16x	16x	16x	4x

As our product line is constantly evolving and expanding, we recommend that you visit logiflex.ca for updates.
En raison de l'évolution constante des lignes de produits, Logiflex vous encourage à consulter les mises à jour au logiflex.ca.

logiflex


1235 St-Roch N., Sherbrooke QC J1N 0H2 Canada
T : 1.877.864.9323 | F : 1.800.474.7830 | logiflex.ca



Printed in Canada | November 2016


1 Attaching the Legs to the Modesty | Assembler les piétements avec le modestie

1.1 Attach the laminate legs to the modesty unit with the dowels. | *Assembler les piétements de mélamine avec modestie à l'aide des goujons.*





2 Securing the Legs to the Modesty | Fixer les piétements au modestie

2.1 From inside the modesty section, secure the legs to the base using the supplied screws. | *De l'intérieur du modestie, fixer les piétements à la base en utilisant les vis fournies.*





3 Preparing the Base | Préparer la base

3.1 Prepare the base unit to receive the surface by inserting the wooden dowels and cams. | *Préparer la base à recevoir la surface en insérant les goujons de bois et les Cam.*



4 Preparing the surface | Préparer la surface

4.1 Prepare the surface by screwing the Pin Cams to the underside of the surface. | *Préparer la surface en vissant les Pin Cam sous la surface.*



5 Assembling the Surface | Assembler la surface

5.1 Place the surface into position. | *Placer la surface sur les piétements.*
5.2 Tighten cams. | *Visser les Cam.*

